

WB23X5340

## Installation Instructions for WB21X5301

This Kits contains: 1 – Sensor  
2 – Wire Nuts  
3 – Installation Instruction

### Step 1: IMPORTANT SAFETY INSTRUCTIONS

**DISCONNECT ALL POWER TO THE RANGE.  
FAILURE TO DO SO COULD RESULT IN  
SERIOUS INJURY OR DEATH.**

Remove screws and old sensor.

**Step 2:** Cut the plastic terminal connector from the range harness and strip the insulation from each wire approximately  $\frac{1}{2}$ " from the end.



**Step 3:** Use the Hi-Temp wire nuts supplied in this kit and connect the wires of the sensor to the wires of the range. This sensor leads and harness leads can be mated in either combination without affecting sensor operation.

**Step 4:** Insert the wire nuts (one at a time) through the oven cavity and the insulation at the back of the cavity. **"IMPORTANT"** – make sure that the wire nuts are completely through the insulation and not against the back of the hot oven cavity. This can be accomplished by using a long narrow screwdriver or a bent coat hanger to capture and properly position the wire and nuts.

**Step 5:** Once the wire nuts are properly positioned, re-install the screws that were removed in Step 1.

