



Installation Guide

1.Tool and Parts needed (**Parts Supplied:**Vent grid assy&Vent grid bracket


Tool needed:Phillips screwdriver)



Vent gird assy




Vent grid bracket (W10449931)





Phillips screwdriver

Step 1:

1.Remove the vent grid






2. Remove the right side screw by Phillips screwdriver



Setp 2:

Install the vent grid bracket into the right side plastic part (use your hand to lift up the crust and then put the grid bracket into the plastic part), finally tighten the screw by Phillips screwdriver.



Setp 3

Reattach the vent grid assy.

Note: the vent grid bracket must be buckled the vent grid assy.

